



NOTE:
Treadle Sol-Ass'y mounted in base on 42".

Key No.	Part No.	Description	Qty.
1	H35006	Nut	4
2	H36728	Lock Washer	4
3	H50535	Screw	4
4	8907	Switch	2
5	6509	Screw	4
6	5BB4018	Cover	1
7	RP410	Spring Pin	5
8	H36040	Nut	4
9	H46288	Screw	2
10	H35007	Nut	1
11	H36734	Lock washer	2
12	H50590	Screw	2
13	HBB2323	Shoe	1
14	8976	Solenoid	1
15	DP45	Dowel Pin	2
16	5BB4015	Roller	2
17	DP69	Dowel Pin	1
18	5BB4013	Lever	1
19	RP412	Spring Pin	1
20	H53731	Setscrew	1
21	HBB4012	Collar	1
22	5BB4014	Yoke	1
23	8364	Spring	4
24	H36040	Self locking Nut	2
25	H46298	Screw	4
26	H46293	Screw	1
27	5BB4008	Yoke	1
28	H36048A	Self Locking Nut	1

29	5BB4017	Bracket	1
30	0BB2006	Spring	1
31	H53740	Setscrew	1
32	5BB4011	Actuator	1
33	0A521-1	Bearing	2
34	5BB4009	Rod Guide	1
35	5BB4006	Treadle Rod	1
36	H49645	Screw	3
37	5BA5019	Base Plate 42" only	1
37	5BB5015	Base Plate	1
38	6027	Screw	4
39	1193	Washer	4
40	5BB5010	Cover Assembly	1
41	5BA2051	Pivot Block	2
42	5BB5017	Foot Pedal	1
43	1738	Retaining Ring	1
44	5BA2052	Flat Washer	1
45	0BA2016	Compression Spring	1
46	1135	Washer	1
47	5BB2321	Plunger	1
48	5BA2161	Nut	2
49	5BB2329	Treadle Rod	1
50	6051	Screw	1
51	1193	Washer	1
52	5BA4018	Treadle Bracket 42" only	1
52	5BA4010	Treadle Bracket 47" & 52" only	1
53	925	Jam Nut	3
54	5BA2185	Block 42" only	1
55	5BA2186	Rod 42" only	1